




**Assembly and Operating Instructions for Outback®
Signature Pro 4S Built-in Gas BBQ**



WD4010-FB0-0B1
OUT371079

Drawings are not to scale.
Specifications subject to change
without prior notice.

CE 2531CU-0071



WARNING

- For outdoor use only. Not for commercial use.
- Read instructions before using the appliance. Failure to follow instructions could result in death, serious bodily injury, and/or property loss.
- Warning: accessible parts may be very hot. Keep young children and pets away.
- Do not move the appliance during use.
- Turn off the gas supply at the gas bottle after use.
- Any modification of the appliance, misuse, or failure to follow the instructions may be dangerous and will invalidate your warranty. This does not affect your statutory rights.
- Retain these instructions for future reference.
- Leak test annually, and whenever the gas bottle is removed or replaced. Check that the hose connections are tight and leak test each time you reconnect the gas bottle.
- For Flare-up control please refer to the 'OPERATION' section of this manual.

FOR YOUR SAFETY


If you smell gas:

1. Shut off gas to the appliance.
2. Extinguish any open flame.
3. Open barbecue lid or hood.
4. If odour continues, discontinue use and contact your local dealer.

FOR YOUR SAFETY

1. Do not store or use petrol or other flammable vapours or liquids in the vicinity of this or any other appliance.
2. A gas bottle not connected for use must not be stored in the vicinity of this or any other appliance.

Expanded View



Key	Description	Outback® Signature Pro 4S Built-in Gas BBQ
1	Warming rack	1
2	#SS 201 modular cooking grid	2
3	#SS 201 circle cooking grid	1
4	Flame tamer	4
5	Body rear support	1
6	Body left side support	1
7	Body right side support	1
8	Fat tray	1
9	Charcoal basket	1

Technical Specifications

	Heat Input for each	Burners	Injector Size	Gas Consumption
Outback® Signature Pro 4S Built-in Gas BBQ	3.5kW	4	0.93mm	1018g/hr
Rear Burner	3.5kW	1	0.93mm	255g/hr

CE Approval Pin Number: 2531CU-0071

Category: I₃₊ (28-30/37)

Gas / Pressure: G30 Butane at 28-30mbar and G31 Propane at 37mbar

Countries of Use: BE, CH, CY, CZ, ES, FR, GB, GR, IE, IT, LT, LU, LV, PT, SK, SI



ASSEMBLY INSTRUCTIONS.

Tools Required: (not included)


Philips head screwdriver




1. Assembly body supports to body




2. Place the fat tray bottom the barbecue body.




3. Place the flame tamers above the burners.



4. Place the cooking grids.




5. Put in the warming rack using the holes provided.




6. Install the charcoal basket


a. Remove the cooking grid




b. And then take out 2pcs of Flame tamer




d. Put the cooking grid back in position



c. Place the charcoal basket inside the barbecue body



7. Unscrew ignition cap and place a Battery (Size: AA, not provided) into place with the (+) end facing outwards. Screw cap back on. Upon pressing the ignition button, a clicking sound will be heard. This is the ignition spark that can be heard.



8. Assemble a Kitchen Countertop as shown.

